

Operation Instruction of Solar Pump Station

SR881

For Split Solar Hot Water System



Please read this instruction carefully!

Contents

SR881 solar pump station installation and commissioning	3
1. Solar pump station with integrated controller	3
1.1 Scope of delivery	3
1.2 About this manual.....	3
1.3 Safety instructions	3
1.4 Station dimensions.....	4
1.5 Specification of components.....	4
2. Mounting station	5
3. Commissioning of station	5
3.1 Flushing and filling the solar system	6
3.2 Flow check.....	7
3.3 Electrical connection	7
Manual of integrated controller of solar station	8
1. Safety information	8
1.1 Installation and commissioning	8
1.2 About this manual.....	8
1.3 Liability waiver.....	8
1.4 Important information	9
1.5 Signal description	9
1.6 Button and HMI description	9
2 Overview	10
2.1 Technical data	10
3. Installation.....	11
3.1 Terminal connection	11
4. System description (Standard solar system with 1 tank, 1 collector field).....	12
5. Time setup	13
6. Function's parameters and options.....	14
6.1 Overview of menu structure	14
6.2 Menu operation description	14
6.3 Value checking and function checking	15
7. Functions operation and parameters setting (for user).....	15
7.1 Timing heating.....	15
7.2 CIRC DHW circulation pump controlled by temperature and time	18

8. Function operation and parameter setup (engineer).....	24
8.1 PWD Password.....	24
8.2 LOAD tank heating.....	24
8.3 COL Collector function.....	26
8.4 COOL Cooling function.....	30
8.5 AUX Auxiliary function.....	33
8.6 MAN Manual operation.....	37
8.7 BLPR Blocking protection	38
8.8 OTDI Thermal Sterilization Function	39
8.9 FS Flow rate monitoring and pump dry-running protection.....	40
8.10 UNIT C-F Switch	42
8.11 RET Reset	42
8.12 PASS Password set.....	43
8.13 Manual heating	43
8.14 ECO Economic mode	44
8.15 DHW circuit pump triggered manually	44
8.16 On/Off controller	44
8.17 Holiday function	45
8.18 Manual circuit function.....	45
9. Protection function.....	45
9.1 Memory function during power failure	45
9.2 Screen protection	45
10 Trouble checking	46
11. Quality Guarantee	47
12. Accessories	48

SR881 solar pump station installation and commissioning

1. Solar pump station with integrated controller

- Integrated solar controller SR881
- Outstanding design
- Assembly with safety valve and manometer
- High-Quality casing for reduce heat loses
- Flow rate check
- Filling and flushing connection unit

1.1 Scope of delivery

- 1* solar pump station
- 1* integrated solar controller
- 1* collector sensor PT1000
- 2* store sensor NTC10K
- 1* wall mounting bracket
- 1* accessory bag (include 2 * screw and dowel ; 2 * strain relief)
- 1*10A power cable
- 1* manual



1.2 About this manual

This solar pump station is a preinstalled and leak-tested group of fitting for transferring heat from the collector to the store. It contains important fittings and safety devices for the operation of the solar thermal system:

- Ball valves in flow and return in combination with check valves to prevent gravity circulation.
- Flow rate check for displaying the flow rate
- Manometer for displaying the system pressure
- Safety valve to prevent inadmissible overpressure
- Flushing and filling unit for flushing, filling and emptying the solar thermal system.

1.3 Safety instructions

The installation and commissioning of the solar station as well as the connection of electrical components requires technical knowledge commensurate with a recognized vocational qualification as a fitter for plumbing, heating and air conditioning technology, or a profession requiring a comparable level of knowledge. The following must be observed

during installation and commissioning:

- The relevant regional and national regulations.
- The technical and safety instructions mentioned in this manual.



Warning: risk of scalding

- There is danger of steam emission with safety valves. Therefore a discharge pipe must be connected to the safety assembly, please observe the enclosed instructions regarding the safety valve when doing this.
- The group of fittings must be installed with sufficient spacing to the collectors because temperatures in the vicinity of the collectors can be very high. An intermediate vessel may be necessary for installation in the attic.
- It is imperative that you make sure the EPDM sealing elements of the solar pump station do not come into contact with substances containing mineral oil. Mineral oil products cause lasting damage to the material, whereby its sealant properties are lost.
- If necessary, ask the manufacturer whether the solar fluid, fats or installation aids contain mineral oils.
- We don't assume liability nor provide warranty for damage to solar station resulting from sealants damaged in this way.

1.4 Station dimensions

Height (with insulation): 420mm

Width (with insulation): 215mm

Depth (with insulation): 150mm

Distance centre to floor: 1600mm

1.5 Specification of components

1.5.1 Return outlet connection (to collector): 3/4 IT

1.5.2 Safety valve: 6bar

1.5.3 Filling connection 3/4 male thread

1.5.4 Connection of expansion vessel 3/4 male thread

1.5.5 Manometer: 0-6bar


1.5.6 Non-return valve: opening pressure 200mmH₂O

1.5.7 Circuit pump: Wilo 15-6 or Grundfos 15-65

1.5.8 Filling connection 3/4 male thread

1.5.9 Digital flow meter 1-16L/min (alternative mechanical flow counter 2-12L/min)

1.5.10 Flow outlet connection (from tank): 3/4 IT



1.5.11 Wire terminal of controller

1.5.12 EPP insulation case

Material:


Fitting: Brass

Seals: PTFE

Insulation: EPP, $\lambda = 0.041 \text{ W / (m.K)}$

Maximum permitted operation pressure: 6Bar

Maximum permitted operation temperature: 120°C



2. Mounting station

- Determine the mounting site of the station.
- Take the station out of packing; remove the front half of the insulation.
- Hold the enclosed wall mounting bracket against the wall and mark the fastening holes, drill holes and insert dowels.
- Fasten the wall mounting bracket to the wall with the screws.
- Push the station against the wall mounting bracket, the station catches and is then attached to the wall.
- Connect the station to the solar thermal system.
- Check the inlet pressure of the expansion vessel and if necessary, adjust it to the local conditions, $P_{\text{inlet}}(\text{bar}) = 1\text{bar} + \Delta H(\text{m}) * 1/10$ (ΔH =height difference between collector and station) .
- Connect the electrical components of the solar station, Attach the store and collector sensor and connect them to the controller, plug the controller into the socket.
- Tighten all nuts and screw connections.
- Attach the front half of the insulation to the station.

3. Commissioning of station



Attention: Risk of scalding!

In order to prevent the boiling of solar fluid in the collectors, the system should not be flushed or filled during periods of strong sunshine.



Attention: Risk of frost!


Solar thermal system cannot be completely emptied after flushing. There is a danger of frost damage if water is used for flushing. Only use solar fluid to flush and fill the solar thermal system. Use water –propylene glycol mixture as solar fluid (Maximum 50% propylene

glycol).

3.1 Flushing and filling the solar system


Flushing and filling steps:

- Disconnect the expansion vessel from the solar thermal system.
- Connect the pressure hose of a flushing and filling station to the fill ball valve A of the solar pump station
- Connect the flushing hose of a flushing and filling station to the drain ball valve B of the solar pump station
- Open the filling ball valve and drain ball valve
- Flush the solar thermal system using the flushing and filling station for at least 15minutes to remove all air from the system.
- During the flushing, bleed the solar thermal system several times at the air stopper until the discharged solar fluid is free of air bubbles.
- Close the drain ball valve of the flushing and filling station, and continues run the filling pump and increase the system pressure to approx.3-4 bar, system pressure can be read from the manometer.
- Close the flushing ball valve B of the solar pump station, and then close the filling valve A, and then stop the flushing and filling station.
- Check the manometer to see whether the system pressure reduces and eliminate leaks where necessary.
- Reconnect the expansion vessel to the solar thermal system.




3.2 Flow check

The flow counter is used for measurement and display of flow rate, in order to guarantee the flawless function of the measuring device the system must be flushed and free from foreign substances.



Digital flow meter (1-16L/min)



Fissol mechanical flow meter (2-12L/min)


3.3 Electrical connection



Warning: disconnect the controller from power supply before opening the housing!

The controller is already integrated in the station and ready to plug in, display and digital counter are already preinstalled at factory. For maintenance or service work, it needs to take out the controller from station, doing follows below steps:

- Switch off the system, disconnect plug from the mains.
- Remove the front half of the insulation.
- Unscrew the cross-recessed screw on the front cover of controller A and remove cover B by pulling it leftwards
- Doing reverse steps to remount the controller.



For further information on electrical connection of the controller, please see manual of controller (terminal layout).

Manual of integrated controller of solar station

1. Safety information

1.1 Installation and commissioning

- When laying wires, please ensure that no damage occurs to any of the constructional fire safety measures presented in the building.
- The controller must not be installed in rooms where easily inflammable gas mixtures are present or may occur.
- The permissible environmental conditions can't be exceeded at the site of installation.
- Before connecting the device, make sure that the energy supply matches the specifications that controller requires.
- All devices connected to the controller must conform to the technical specifications of the controller.
- All operations on an open controller are only to be conducted cleared from the power supply. All safety regulations for working on the power supply are valid.
- Connecting and /or all operations that require opening the collector (e.g. changing the fuse) are only conducted by specialists.

1.2 About this manual

This manual describes the mounting, functions and operation of a solar controller used for a solar hot water system, for mounting of other devices of a completed solar hot water system like solar collector, pump station and storage, please is sure to observe the appropriate installation instructions provided by each manufacturer. Mounting, wire connecting, commissioning and maintenance of this controller may only be performed by the trained professional person; the professional person should be familiar with this manual and follow the instructions contained herein.

1.3 Liability waiver

The manufacturer can't monitor the compliance with these instructions or the circumstances and methods used for installation, operation, utilization and maintenance of this controller. Improper installation can cause damages to material and person. This is the reason why we do not take over responsibility and liability for losses, damages or cost that might arise due to the improper installation, operation or wrong utilization and maintenance or that occurs in some connection with the aforementioned. Moreover we do not take over liability for patent infringements or infringements – occurring in connection with the use of this controller on the third parties rights. The manufacturer preserves the right to put changes to product, technical data or installation and operation instructions without prior notice. As soon as it

becomes evident that safe operation is no longer possible (e.g. visible damage). Please immediate take the device out of operation. Note: ensure that the device can't be accidentally placed into operation.

1.4 Important information

We have carefully checked the text and pictures of this manual and provided the best of our knowledge and ideas, however inevitable errors maybe exist. Please note that we cannot guarantee that this manual is given in the integrity of image and text, incorrect, incomplete and erroneous information and the resulting damage we do not take responsibility.

1.5 Signal description



Safety indication: Safety instructions in the text are marked with a warning triangle.


They indicate measures which can lead to injury of person or safety risks.

Operation steps: small triangle “►” is used to indicate operation step.



Note: contains important information about operation or functions.

1.6 Button and HMI description



Nr.	Button
1	LCD Display screen
2	Power indication lamp
3	"On/Off"
4	"Manual Heating"
5	"Manual Circuit"
6	"Eco Mode"
7	"Holiday"
8	"Clock"
9	Downwards adjust "-"
10	"Exit"
11	"Set"
12	Upwards adjust "+"

Status Description	Code	Lighting	Blinking
Exceed the maximum temperature of storage	SMX		
Running of storage emergency shutdown function			
Running of collector emergency shutdown function	OCEM		 + 
Running of collector cooling	OCCO		
Running of tank cooling function	OSTC		
Start of anti-freezing function	OCFR		
Running of anti-freezing function	OCFR		

2 Overview

2.1 Technical data

- **Power supply:** 100...240V ~(50...60Hz)
- **Rated impulse voltage:** 2.5KV
- **Housing:** Plastic ABS
- **Mounting:** Wall mounting
- **Operation:** 10 push buttons at the front cover
- **Protection type:** IP40

Note: there are 4 inputs for NTC10K, B=3950 temperature sensor, but only 2 sensors are included in the standard delivery list; the other two should be purchased separately by customer if necessary.

3. Installation




Note: Power can only be switched on under the control of the housing are closed situation. The installer must make sure that the controller's IP security level is not destroyed during the installation process.

Depending on the type installation, put the cable wires from the plastic cover behind the access hole.

NOTE: The flexible wire must be fastened to the case using the strain-relief clamps provided.

3.1 Terminal connection




● Input ports

- T1: PT1000 temperature sensor, for measuring the temperature of collector
- T2 ~T5: NTC10K, B=3950 temperature sensor, for measuring temperature of tank and pipe.
- FRT: For rotary vane type electronic flowmeter

● Output ports

- Input Ports L, N: for power connection, L: live wire, N: zero wire, protective wire, with 10A power plug.
- Output R1: Electromagnetic relays, Max. Current: 2A
- Output R2: Electromagnetic relays, Max. Current: 2A
- Output R3: Electromagnetic relays, Max. Current: 2A
- **Output HR: Electromagnetic relays, designed for on/off control of back-up heating device, Max. Current: 10A (@AC230V, for $\leq 1500W$ electrical heater,**



@110VAC, for $\leq 750\text{W}$ electrical heater)


● **Advice regarding the installation of temperature sensors:**

- Only original factory equipped Pt1000 temperature sensors are approved for using with the controller, it is equipped with 1.5m silicon cable and suitable for all weather conditions, the cable is temperature resistant up to 280°C , connect the temperature sensors to the corresponding terminals with either polarity.
- Only original factory equipped NTC10K,B=3950 temperature sensors are approved for using with tank and pipe, it is equipped with 3m PVC cable, and the cable is temperature resistant up to 105°C , connect the temperature sensors to the corresponding terminals with either polarity.
- All sensor cables carry low voltage, and to avoid inductive effects, must not be laid close to 230 volt or 400 volt cables (minimum separation of 100mm).
- If external inductive effects are existed, e.g. from heavy current cables, overhead train cables, transformer substations, radio and television devices, amateur radio stations, microwave devices etc., then the cables to the sensors must be adequately shielded.
- Sensor cables may be extended to a maximum length of ca. 100 meter, when cable's length is up to 50m, and then 0.75mm^2 cable should be used. When cable's length is up to 100m, and then 1.5mm^2 cables should be used.

4. System description (Standard solar system with 1 tank, 1 collector field)

Description:

The controller calculates the temperature difference between collector sensor T1 and tank sensor T2. If the difference is larger than or identical to the adjusted switch-on temperature difference, the solar circulation pump (R1) will be switched on and the tank will be loaded until the switch-off temperature difference or the maximum tank temperature is reached.



Sensor ports	Description		Relay outputs	Description
T1	Collector temperature sensor PT1000		R1	For solar circuit pump
T2	Temperature sensor on the bottom part of tank. NTC10K		HR	For back-up heating
T3	Temperature sensor on the upper part of tank. NTC10K			

Auxiliary functions

Function code	Function description	Sensor	Relay output
CIRC	DHW circulation (controlled by temperature or flow impulse)	T4/flow switcher (connected on T6 port)	R2
OHDP	Thermal transfer -by external radiator		R2/R3 optional
TIMER	Timer function		R3
AH	Thermostat function	T2/T3/T5 optional	R3

i Note: when R3 output is selected for OHDP function, other two functions AH, TIME will be closed automatically. When one of these three functions (HEAT, OHDP, SFB) is activated, and then the other two will be deactivated automatically.

5. Time setup



Before switch-on the power, please connect sensor on the inputs terminal, connect pump or on/off valve on the outputs terminal. After the power is switched-on, you can set the time, password and parameters of system.

► Press “Clock” button, Time displays on the screen, hour “00” blinks on the display.

► Press “+/-” button, to adjust hour

► Press “Clock” button again, minute time “00” blinks on the display

► Press “+/-” button to adjust minute


► Press “ESC” button to save the set value



i Note: In the case power to controller is switched-off, date and time will be memorized in controller for 36 hours.

6. Function's parameters and options

6.1 Overview of menu structure



6.2 Menu operation description

● Access main menu

- ▶ Press "SET" button to access main menu
- ▶ Press "+/-" to select menu
- ▶ Press "SET" button to enter the submenu



● Access submenu

- ▶ After selecting main menu, then press "SET" button to access submenu
- ▶ Press "+/-" button to select submenu,
- ▶ Press "SET" button to enter the value adjust interface
- ▶ Press "+/-" to adjust value

► Press “SET” or “ESC” to confirm the value you set

► Press “ESC”, exit the submenu.

i Note: Enter the menu adjustment interface, if you don't press any button within 3 minutes, screen will exit the adjustment and turn to main interface.

6.3 Value checking and function checking

Under normal running status of controller, press “+/-” button to check the measured value of temperature of collector and tank, value of flow rate (L/M), status of thermal sterilization function, status of auxiliary functions, status of voltage of battery(VOL), running time of display (DAYS), running time of controller (MDAY), program version of display (SW), and program version of main controller (SW-M)

i Note:

- Flow rate, thermal sterilization function, auxiliary functions can only be displayed only when these functions are triggered.
- When thermal sterilization function is running, time of thermal sterilization can be checked. When one of any auxiliary functions is running, its corresponding signal blinks on the display.
- SW: program version of display, SW-M: program version of controller.
- DAYS:running time of display; MDAY:running time of controller
- When you already in the interface of value checking function, if no any button is pressed within 3 minutes, the display will return to the main interface.



7. Functions operation and parameters setting (for user)

7.1 Timing heating

Function description:

Electrical heater or gas / oil boiler is normally used as back-up heating source of a solar hot water system. Through this timing heating function controller can keep the tank temperature constantly. When tank temperature (T3) drops below the switch-on thermostats temperature, back-up heating output HR is triggered, when T3 rises up to the switch-off thermostats temperature, HR is ceased.

● Set time sections and temperature for timing heating

Factory set:

- ✧ The first time section: default at 4:00 to start heating, and at 5:00 to stop heating, and the switch-on temperature of heating is 40°C, switch-off temperature is 50°C.
- ✧ The second time section: default at 10:00 to start heating, and at 10:00 to stop heating,
- ✧ The Third time section: default at 17:00 to start heating, and at 22:00 to stop heating, and the switch-on temperature of heating is 50°C, switch-off temperature is 55°C.

If you set the start time and close time with a same value, which means within this time

section, the timing heating function is switched-off. For example, at the second time section, start time is set at 10:00, but close time is also set at 10:00.

Timing heating function is run at the preset time section, 3 time sections can be set, and within every time section, the desired temperature may be different. The adjustable range of switch-on temperature is 0°C ~ (OFF-2°C), switch-off temperature range is (ON+2°C) ~ 95°C.

● **SMT Intelligent heating**

At the case that solar energy is insufficient to heat the tank, in order to ensure user has sufficient hot water, controller will check the temperature of tank automatically at the preset time, if tank's temperature is not reached to the desired temperature, then back-up heat device will be triggered, and when tank's temperature rises up to the desired value, then back-up heat device stops.


Factory set: (impossible to be adjusted)

- ✧ Default at 13:00 of the first time section to trigger the back-up heat device to heat tank to 30 °C,
- ✧ Default at 14:00 of the second time section to trigger the back-up heat device to heat tank to 35 °C,
- ✧ Default at 15:00 of the third time section to trigger the back-up heat device to heat tank to 40 °C,
- ✧ Default at 16:00 of the forth time section to trigger the back-up heat device to heat tank to 45 °C,
- ✧ Default at 17:00 of the fifth time section to trigger the back-up heat device to heat tank to 50 °C.



Note:

1. If larger power electrical heater (larger than 1500KW) is used, according to the power, we suggest using controller with 3000W or 4000W output.
2. Please remark the power of electrical heater and the voltage used.

Menu Structure

Main menu	Submenu	Factory set	Adjustable range	Step per adjust	Description
THET					Timing heating function
	THTS	S2	S2. S3		Select desired sensor of heated tank (S3 for T3, S2 for T2)
	SMT	OFF	ON/OFF		Intelligent heating Mode
	tH1O	04:00 / 40°C	00:00-23:59/ 0-93°C	0.5C	Switch-on time and temperature of the first heating section
	tH1F	05:00/ 50°C	00:00-23:59/ 2-95°C	0.5C	Switch-off time and temperature of the first heating section
	t H2O	10:00 / 40°C	00:00-23:59/ 0-93°C	0.5C	Switch-on time and temperature of the second heating section
	tH2F	10:00 / 50°C	00:00-23:59/ 2-95°C	0.5C	Switch-off time and temperature of the second heating section
	tH3O	17:00 / 50°C	00:00-23:59/ 0-93°C	0.5C	Switch-on time and temperature of the third heating section
	tH3F	22:00 / 55°C	00:00-23:59/ 2-95°C	0.5C	Switch-off time and temperature of the third heating section

Function setting:

► Press “SET” button to access main menu, and select THET timing heating menu.

THET

► Press “SET” button to set parameter, firstly to select the desired sensor for the heated tank, “THTS S2” displays on the screen.

THTS
S2

► Press “SET” button, “S2” blinks

► Press “+/-” button to select desired sensor

► Press “SET” or “ESC” button to save the setting.

► Press “+” button to access submenu of the intelligent heating, “SMT OFF” displays on the screen

SMT
OFF

► Press “SET” button, “OFF” blinks

- ▶ Press “+/-” button to activate this function
- ▶ Press “SET” or “ESC” button to save the setting.
- ▶ Press “SET” button to access the window of the switch-on time and temperature of the first heating section, “th1O 04: 00” displays on the screen.



- ▶ Press “SET” button, hour time “04” blinks
- ▶ Press “+/-” button to adjust hour of the switch-on time
- ▶ Press “SET” button, minute time “00” blinks
- ▶ Press “+/-” button to adjust minute of the switch-on time
- ▶ Press “SET” button, temperature “40” blinks
- ▶ Press “+/-” button to adjust the switch-on temperature
- ▶ Press “SET” or “ESC” button to save the setting.



- ▶ Press “+” button to access the window of the switch-off time and temperature of the first heating section, “th1F 05: 00” displays on the screen



- ▶ Press “SET” button, hour time “05” blinks
- ▶ Press “+/-” button to adjust hour of the switch-off time
- ▶ Press “SET” button, minute time “00” blinks
- ▶ Press “+/-” button to adjust minute of the switch-off time
- ▶ Press “SET” button, temperature “50” blinks
- ▶ Press “+/-” button to adjust the switch-off temperature
- ▶ Press “SET” or “ESC” button to save the setting.
- ▶ Press “+” button to access the window of the switch-on time and temperature of the second heating section, repeat above steps to set time and temperature for the second and third heating section.



Note: definition of timing heating sign

- 1) Within the preset time section, if timing heating isn't working, heating sign  is lighted on the screen
- 2) Within the preset time section, if timing heating is working, heating sign  blinks on the screen.
- 3) Out of the preset time section, heating sign  doesn't display on the screen.

7.2 CIRC DHW circulation pump controlled by temperature and time

Function description:

This function is designed to get warm water quickly when customer opens the stopcock. In the case stopcock is closed, hot water pipe is also used as the circuit pipe. Two hot water circuit supply modes are available in this controller: temperature controlled mode and timing

flow switcher controlled circuit mode. For using this function, an extra pump R2 and a flow switcher or a temperature sensor (mounted on the hot water return pipe (T4)) should be installed in the system.

Two control modes of CIRC pump:

- Within three time sections/ temperature controlled
- Within three time sections/ flow switcher controlled




Note:

1. for 2 DHW control modes, only one mode can be selected from three time - sections/temperature control mode and three time - sections /flow switcher control mode,
2. for 2 DHW control modes, three time - sections/temperature control mode and three time - sections /flow switcher control mode, their parameters adjust steps of two control mode are same.

- **Three time - sections / temperature control mode (tEP)**

Within the time - section (default: DHW temperature is less than 40°C, DHW circuit pump is trigger, when temperature rises to 45°C, DHW circuit pump is stopped).

Trigger on conditions of temperature controlled DHW circuit pump (STAT): when tank temperature (upper temperature T3 is priority sensor) is 2°C higher than the preset switch-off temperature of this function (CYCF), DHW pump just can be triggered.



Default time - section set:

- The first time - section: starts at 05:00 and stops at 07:00 a.m.
- The second time - section: starts at 11:00 a.m. and stops at 13:00 p.m.
- The third time - section: starts at 17:00 and stops at 22:00 p.m.



Note: if sensor T4 is installed, in order to avoid measuring error, please keep sensor's position to tank is 1.5m far.


- **Three time - sections / flow switcher control mode (FS)**

Function description:

Open the stopcock, water flows through pipe, a flow signal is felt by a flow switcher which is mounted on the cold-water pipe and sent to the controller, and then controller will trigger the

DHW circuit pump (R2) and it pumps hot water from tank to the circuit pipe. The running time of circuit pump is adjustable, when the preset time runs out, pump stops.

This stopcock seems like a remote controller to control the running of circuit pump. This operation mode is an environment-friendly, energy-saving control solution.



Open the stopcock for a shortly time, the flow switcher which is mounted on the cold flow pipe of tank will feel the flow signal, and then controller will trigger the circuit pump R2, and pump will feed hot water from tank to the pipe. Then when you re-open the stopcock, hot water flows out immediately. Once the pump's running time finishes, then pump is stopped. When hot water is not used, to avoid the heat releasing through pipe due to the running of circuit pump, controller will stop the pump after the pre-set running time. To avoid the pump being re-triggered just after it stopped, parameter "rest time" is used for this control.

Open the stopcock within a pre-set time - section, pump running as the default design: pump running for every three minutes and then rest for 15minutes (the adjustable range of the running time is 1-30 MIN and the rest time is 0-60MIN)

Note:

- A check valve should be installed before pump to avoid the water which is from tank being mixed with water from circuit pipe.
- If the stop time is set with value 0 minute, then when flow switcher feels the flow and thus to trigger the pump, pump will run for the whole time - section. And when the stopcock is closed, pump is stopped automatically.

Default time - section set:


- The first time - section: starts at 05:00 and stops at 07:00 a.m.
- The second time - section: starts at 11:00 and stops at 13:00
- The third time - section: starts at 17:00 and stops at 22:00 p.m.

● **Flow switch fitting:**

Material of fitting: brass

House: plastic

Connection: G3/4




Reed of flow switcher: Max 300V DC/1A



Note:

- Noting the flow direction indicated on the flow switcher!
- No polarity of wires from flow switcher to the controller.
- Flow switcher is not included in the delivery list of this controller, please buy it separately.

Menu structure



Main menu	Submenu 1	Submenu 2	Default set	Adjust range	Adjust step	Main menu
CIRC			OFF	ON/OFF		DHW circuit function
	MODE		FS	tEP/FS		Mode selection: tEP temperature control mode FS flow switcher control mode
		STAT	ON	ON/OFF		Trigger condition of DHW circuit pump Tank temperature (T3 priority) is 2°C higher than the switch-off temperature (CYFC) , only available in temperature control mode
		CYCO	40°C/3min	5-53°C/1-30min	0.5°C/1min	Switch-on temperature or running time
		CYCF	45°C/15min	7-55°C/0-60min	0.5°C/1min	Switch-off temperature or rest time

		t C1O	05:00	00:00-23:59		Start time of the first time-section
		t C1F	07:00	00:00-23:59		Close time of the first time-section
		t C2O	11:00	00:00-23:59		Start time of the second time-section
		t C2F	13:00	00:00-23:59		Close time of the second time-section
		t C3O	17:00 /	00:00-23:59 /		Start time of the third time-section
		t C3F	22:00	00:00-23:59		Close time of the third time-section

Function set: (take DHW three time - sections temperature control mode as example)

► Press "SET" button, select main menu CIRC



► Press "SET" button, "CIRC OFF" displays on the screen

► Press "SET" button, "OFF" blinks

► Press "+/-" button to activate the function, "CIRC ON" displays



► Press "SET" or "ESC" button, to confirm the setting

► Press "+", "MODE FS" displays on the screen (three time - sections temperature control)

► Press "SET" button, "FS" blinks on the screen

► Press "+/-" button to select control mode, three-time sections/ temperature control mode.



► Press "SET" or "ESC" button, to confirm the setting

► Press "+", "STAT ON" displays on the screen (trigger on conditions, this menu only available in the temperature control mode)

► Press "SET" button, "ON" blinks on the screen

► Press "+/-" button to deactivate this function

► Press "SET" or "ESC" button, to confirm the setting



► Press "+", "CYCF 40°C" displays on the screen, to set the switch-on temperature of circuit pump function(if select flow switcher control mode, then here "CYCO 03Min" displays



► Press "SET" button, "40°C" blinks

► Press "+/-" to adjust the switch-on temperature of this function, adjust range is 0°C ~ (OFF-2°C)

► Press "SET" or "ESC" button, to confirm the setting

► Press “+”, “CYCF 45°C” displays on the screen, to set the switch-off temperature of circuit pump function



► Press “SET” button, “45°C” blinks

► Press “+/-” to adjust the switch-off temperature of this function, adjust range is (ON+2°C ~ 55°C)

► Press “SET” or “ESC” button, to confirm the setting

► Press “+”, “tC1O 05:00” displays on the screen, to set the start time of the first time section

► Press “SET” button, hour zone “05” blinks

► Press “+/-” to adjust the hour of start time of the first time section

► Press “SET” button, minute zone “00” blinks

► Press “+/-” to adjust the minute of the start time of the first time section

► Press “SET” or “ESC” button, to confirm the setting



► Press “+”, “tC1F 07:00” displays on the screen, to set the close time of the first time section


► Press “SET” button, hour zone “07” blinks

► Press “+/-” to adjust the hour of the close time of the first time section

► Press “SET” button, minute zone “00” blinks

► Press “+/-” to adjust the minute of the close time of the first time section

► Press “SET” or “ESC” button, to confirm the setting



► Press “+”, to enter the setting of the second time section, doing as above described steps to set time of second and third time section.

If it is needed to close one time - section, then just set the start time and close time with a same time. (Example: at 10:00 start circuit, and at 10:00 close the circuit)

8. Function operation and parameter setup (engineer)

8.1 PWD Password



Access main menu, select “PWD 0000” to enter password

- ▶ Press “SET” button, the left digital blinks, enter password, factory set is “0000”
- ▶ Press “+/-”, to enter the first digital
- ▶ Press “SET”, the second digital blinks
- ▶ Press “+/-” to enter the second digital
- ▶ Press “SET”, the third digital blinks
- ▶ Press “+/-” to enter the third digital
- ▶ Press “SET”, the forth digital blinks
- ▶ Press “+/-” to enter the forth digital
- ▶ Press “SET”, to access main menu



Through password set to limit the user to change some parameters, 4 digitals needed.
Default is 0000

If no password is set, then just press “SET” five times to access main menu directly.

8.2 LOAD tank heating

Function description:

● ΔT control logic

The controller works as a standard temperature differential controller. If the temperature reaches or exceeds the switch-on temperature difference (DTO), the pump R1 switches on. When the temperature difference reaches or falls below the adjusted switch-off temperature difference (DTF), the respective relay R1 switches off.




Note: The switch-on temperature difference must be 0.5 K higher than the switch-off temperature difference. The set temperature difference must be at least 0.5 K higher than the switch-on temperature difference.

● SMX Maximum tank temperature protection set

If the tank temperature reaches the adjusted maximum temperature, the tank will no longer be loaded in order to avoid damage caused by overheating. If the maximum tank temperature is exceeded, sign  is displayed on the screen.

The sensor for tank maximum limitation (SMA_X) can be selected. The maximum limitation always refers to the sensor selected (T2 or T3). The switch-on hysteresis (HYST) is selectable (Default is 2°C), for example, when tank maximum temperature is set to 70°C, then at 68°C, Maximum tank temperature protection function is deactivated automatically.

Menu Structure



Main menu	Sub menu	Factory set	Adjustable range	Step per adjust	Description
LOAD					Tank heating
	DTO	6K	1-50K	0.5K	Switch-on temperature difference of tank heating
	DTF	4K	0.5-49.5K	0.5K	Switch-off temperature difference of tank heating
	SMX	70°C	4-95°C	1°C	Maximum temperature of tank
	SMA X	S2	S2, S3		Sensor for Maximum temperature of tank (S3 for T3 , S2 for T2)
	HYST	2K	0.1-10K	0.1K	Hysteresis of maximum temperature of tank

Setup the function

- ▶ Select “LOAD” main menu
- ▶ Press “SET”, “DTO 6K” displays on the screen
- ▶ Press “SET”, “6K” blinks
- ▶ Press “+/-”, to adjust the switch-on temperature of the solar circuit pump
- ▶ Press “SET” or “ESC” to save the setting
- ▶ Press “+”, “DTF 4K” displays on the screen

- ▶ Press “SET”, “4K” blinks
- ▶ Press “+/-”, to adjust the switch-off temperature of solar circuit pump
- ▶ Press “SET” or “ESC” to save the setting

- ▶ Press “+”, “SMX 70°C” displays on the screen

SMX
70.0°C

- ▶ Press “SET”, “70°C” blinks

- ▶ Press “+/-”, to adjust the maximum temperature of tank

- ▶ Press “SET” or “ESC” to save the setting

- ▶ Press “+”, “SMAX S2” displays on the screen

SMAX
S2

- ▶ Press “SET”, “S2” blinks

- ▶ Press “+/-”, select the sensor for maximum temperature of tank (S3 for T3, S2 for T2)

- ▶ Press “SET” or “ESC” to save the setting

- ▶ Press “+”, “HYST 2K” displays on the screen

HYST
02.0K

- ▶ Press “SET”, “2K” blinks

- ▶ Press “+/-”, to adjust the hysteresis of tank maximum temperature

- ▶ Press “SET” or “ESC” to save the setting

8.3 COL Collector function

Function description

● OCEM Collector emergency shutdown

When the collector temperature exceeds the adjusted collector emergency temperature, Then solar pump (R1) switches off in order to protect the system components against overheating (collector emergency shutdown). If the maximum collector temperature (OCEM) is exceeded, sign blinks on the screen.



Warning! Risk of injury! Risk of system damage by pressure surge! If water is used as the heat transfer fluid in pressure systems, water will boil at 100 °C. Then do not set the collector limit temperature higher than 95 °C.

● OCCO Collector cooling

The collector cooling function keeps the collector temperature rising within the operating range by heating the tank. If the tank temperature reaches 95°C the function will be switched off for safety reasons.

When the tank temperature exceeds the adjusted maximum temperature of tank, then solar system is switched off. If the collector temperature rises up to its adjusted maximum collector temperature, the solar pump is switched on again until the collector temperature

falls below the maximum collector temperature. The tank temperature may then exceed its maximum temperature, but only up to 95°C (emergency shutdown of the tank), and sign  blinks on the screen, system stops.

If the collector cooling is active,  blinks on the screen.

 **Note:** This function is only available when the heat transfer function (OHDP) is not activated.

- **OCMI Collector minimum temperature**

The minimum collector temperature is the lowest temperature of collector, only when collector temperature is higher than that temperature, solar pump (R1) just can be switched-on, if the collector temperature falls below the adjusted minimum temperature, Sign  blinks on the screen (slowly blinks).


- **OCFR Collector antifreeze function**

Collector antifreeze function activates the loading circuit between the collector and the tank when the collector temperature falls below the adjusted temperature **CFRO**. This will protect the fluid against freezing or coagulating. If collector temperature exceeds the switch-off temperature of collector antifreeze function CFRF, the solar pump will be switched off again.

If collector antifreeze function is activated, sign  blinks on the screen.

 **Note:** Since this function uses the limited heat which is saved in the tank, so the antifreeze function should be used only in regions where the ambient temperature is around the freezing point only for a few days.

Menu structure



Main menu	Submenu 1	Submenu 2	Factory set	Adjustable range	Step per adjust	Description
COL						Collector function
	OCEM		ON			Collector emergency shutdown function on/off
		CEM	130°C	80-200°C	1°C	Temperature of collector emergency shutdown(hysteresis 10K)
	OCCO		OFF			Collector cooling function on/off
		CMAx	110°C	70-160°C	1°C	Temperature of collector cooling (hysteresis 5°C)
	OCMI		OFF			Collector minimum temperature function on/off
		CMIN	10°C	10-90°C	1°C	Temperature of collector minimum function
	OCFR		OFF			Anti-freeze function on/off
		CFRO	4°C	-40-8°C	0.5°C	Switch-on temperature of anti-freeze function
		CFRF	5°C	-39-9°C	0.5°C	Switch-off temperature of anti-freeze function

Function setting:**OCEM (Collector emergency shutdown function) setup**

- ▶ Select “COL” function menu
- ▶ Press “SET”, “OCEM” displays on the screen
- ▶ Press “SET” again, “OCEM ON” displays on the screen
- ▶ Press “SET”, “ON” blinks on the screen

(If it is necessary to shut down this function, press “+/-” to deactivate it)

- ▶ Press “SET” or “ESC” to save the setting
- ▶ Press “+”, “OCEM 130°C” displays on the screen
- ▶ Press “SET”, “130°C” blinks on the screen
- ▶ Press “+/-”, to adjust the temperature of the collector emergency function
- ▶ Press “SET” or “ESC” to save the setting
- ▶ Press “ESC” to return to previous menu

COL

OCEM
OnOCEM
1300°C

OCCO (Collector cooling function) setup

- ▶ Select OCCO submenu, "OCCO" displays on the screen
- ▶ Press "SET", "OCEM OFF" displays on the screen
- ▶ Press "SET", "OFF" blinks on the screen
- ▶ Press "+/-", to activated this function, "OCEM ON" displays on the screen
- ▶ Press "+", "CMAX 110°C" displays on the screen
- ▶ Press "+/-", to adjust the switch-on temperature of collector cooling function
- ▶ Press "SET" or "ESC" to save the setting
- ▶ Press "ESC" to return to previous menu





OCMI (Collector minimum temperature) setup

- ▶ Select OCMI submenu, "OCMI" displays on the screen
- ▶ Press "SET", "OCMI OFF" displays on the screen
- ▶ Press "SET", "OFF" blinks on the screen
- ▶ Press "+/-", to activate this function, "OCMI ON" displays on the screen
- ▶ Press "+", "OCMI 10°C" displays on the screen
- ▶ Press "+/-", to adjust the minimum temperature of collector
- ▶ Press "SET" or "ESC" to save the setting
- ▶ Press "ESC" to return to previous menu





OCFR (Antifreeze function) setup

- ▶ Select OCFR submenu, "OCFR" displays on the screen
- ▶ Press "SET", "OCFR OFF" displays on the screen
- ▶ Press "SET", "OFF" blinks on the screen
- ▶ Press "+/-", to activate this function, "OCFR ON" displays on the screen
- ▶ Press "+", "CFRO 4°C" displays on the screen
- ▶ Press "SET", "4°C" blinks on the screen
- ▶ Press "+/-", to adjust the switch-on temperature of antifreeze function
- ▶ Press "SET" or "ESC" to save the setting
- ▶ Press "+", "CFRF 5°C" displays on the screen
- ▶ Press "SET", "5°C" blinks on the screen






- ▶ Press “+/-”, to adjust the switch-off temperature of antifreeze function
- ▶ Press “SET” or “ESC” to save the setting
- ▶ Press “ESC” to return to previous menu

8.4 COOL Cooling function

Function description

2 cooling functions for different devices can be activated by this function: tank cooling, heat transferring by external radiator

● OSTC Tank cooling

When the tank cooling function is activated, the controller aims to cool down the tank during the night in order to prepare it for solar loading on the following day. If the tank temperature exceeds the adjusted maximum tank temperature SMAX, the collector temperature falls below the tank temperature and downwards to the switch-on temperature difference DTCO of this cooling function, then system will be activated in order to cool down the tank by releasing the energy through the collector.

If tank cooling function is activated, sign  blinks on the screen



Note: if tank temperature reaches to 95 °C, all cooling functions will be locked.

Hysteresis switch on temperature difference is 5K.

● OHDP Heat transferring by external radiator

Heat transferring by external radiator function is designed to transfer the excess heat which is generated under the strong solar irradiation through an external heat exchanger (e. g. fan coil); the purpose is to keep the collector's or tank's temperature within the operating range. For this function, an extra output should be added (R2 or R3 as option)

Heat transferring by external radiator function can control either an additional pump or a valve (**OTPM ON** = pump logic, **OTPM OFF** = valve logic).


Pump logic controlled thermal transferring function:

If the temperature (T1) of collector reaches the set point of switch-on temperature, pump (R2/R3) will be triggered. If the temperature (T1) of collector drops below 5K to the over-heat temperature, pump (R2/R3) will be ceased.


Valve logic controlled thermal transferring function:

If the temperature (T1) of collector reaches the set point of the switch-on temperature, temperature difference circuit pump (R1) and valve (R2/R3) will be triggered simultaneously. If the temperature (T1) of collector drops below 5K to the over-heat temperature, pump (R1) and valve (R2/R3) will be ceased simultaneously.

Below is the example of this application for reference.



Collector valve logic heat transferring




Collector pump logic heat transferring

- Sign  displays on the screen, it indicates that valve logic heat transferring is running.
- Sign  displays on the screen, it indicates that pump logic heat transferring is running.

Note:

1. When collector overheat temperature OTST is 10K below the CEM temperature of collector emergency shutdown, then collector overheat temperature OTST is locked
2. Heat transferring function is only available when collector cooling function (OCCO) is deactivated.

Menu structure



Main menu	Submenu 1	Submenu 2	Factory set	Adjustable range	Step per adjust	Description
COOL						Cooling function
	OSTC		OFF	ON/OFF		Tank cooling function

		DTCO	20K	1-30K	0.5K	Switch-on temperature difference of cooling function
		DTCF	15K	0.5-29.5K	0.5K	Switch-off temperature difference of cooling function
	OHDP		OFF	ON/OFF		Heat transferring by external radiator (only in case there is available output)
		OTST	80°C	20-160°C	1°C	Temperature set point for heat transferring (hysteresis 5°C)
		OTPM	ON	OTPM ON=pump Logic OTPM OFF=Valve logic		Pump control logic and valve control logic
		REL	R3	R3,R2		Output ports

Function setting:**OSTC (Tank cooling) setup**

- ▶ Select “OSTC” function submenu,”OSTC” displays on the screen
- ▶ Press “SET”, “OSTC OFF” displays on the screen
- ▶ Press “SET”, “OFF” blinks on the screen
- ▶ Press “+/-”, to activate this function
- ▶ Press “+”, “DTCO 20K” displays on the screen
- ▶ Press “SET”, “20K” blinks on the screen
- ▶ Press “+/-”, to adjust the switch-on temperature difference of tank cooling function
- ▶ Press “SET” or “ESC” to save the setting
- ▶ Press “+”, “DTCF 15K” displays on the screen
- ▶ Press “SET”, “15K” blinks on the screen
- ▶ Press “+/-”, to adjust the switch-off temperature difference of tank cooling function
- ▶ Press “SET” or “ESC” to save the setting
- ▶ Press “ESC” to return to previous menu





OHDP (Heat transferring) setup

- ▶ Select “OHDP” function sub-menu,”OHDP” displays on the screen
- ▶ Press “SET”, “OHDP OFF” displays on the screen



- ▶ Press “SET”, “OFF” blinks on the screen
- ▶ Press “+/-”, to activate this function, “OHDP ON” displays on the screen


 LCD screen showing "OHDP" on the top line and "OFF" on the bottom line.

- ▶ Press “+”, “OTST 80°C” displays on the screen
- ▶ Press “SET”, “80°C” blinks on the screen
- ▶ Press “+/-”, to adjust the switch-on temperature of heat transferring function


 LCD screen showing "OTST" on the top line and "800°C" on the bottom line.

- ▶ Press “SET” or “ESC” to save the setting
- ▶ Press “+”, “OTPM ON” displays on the screen
- ▶ Press “SET”, “ON” blinks on the screen
- ▶ Press “+/-”, to select pump logic or valve logic for heat transferring function
- ▶ Press “SET” or “ESC” to save the setting
- ▶ Press “+”, “REL 3” displays on the screen
- ▶ Press “SET”, “3” blinks on the screen
- ▶ Press “+/-”, to select the output port for heat transferring function
- ▶ Press “SET” or “ESC” to save the setting
- ▶ Press “ESC” to return to previous menu


 LCD screen showing "REL" on the top line and "3" on the bottom line.

8.5 AUX Auxiliary function

Function description:

● TIME Timer function

Timer function can trigger controller's output port at the preset time; therefore, an available output (R3) is needed.

● AH Thermostat function


The thermostat function works independently from the solar operation and can be used for using surplus energy to reduce tank temperature or for using after heating to rise tank temperature. (Every day 3 heating time sections can be set),




Note:

- **AH O < AH F:** Thermostat function is used for after heating
- **AH O > AH F:** Thermostat function is used for releasing surplus energy from tank.
 - ✧ When sign **AH** displays on the screen, it indicates that thermostat function is activated.
 - ✧ When sign **AH** blinks on the screen (blinks quickly) , it indicates that thermostat function (heating) is running.
 - ✧ When sign **AH** blinks on the screen (blinks slowly) , it indicates that thermostat

function （heat releasing） is running.



After heating




Releasing heating

● **BEEP Beeper fault warning**

When system has fault (temperature sensor fault, no flow etc), beeper sends out warning

Menu Structure



Main menu	Submenu 1	Submenu 2	Factory set	Adjustable range	Step per adjust	Description
AUX						Auxiliary functions
	TIME		OFF	ON/OFF		Timer function
		t 1O	00:00	00:00-23:59		Start time of the first time section
		t 1F	00:00	00:00-23:59		Close time of the first time section
		t 2O	00:00	00:00-23:59		Start time of the second time section
		t 2F	00:00	00:00-23:59		Close time of the second time

				59		section
		t 3O	00:00	00:00-23:59		Start time of the third time section
		t 3F	00:00	00:00-23:59		Close time of the third time section
	AH		OFF	ON/OFF		Thermostat function
		AHS	S3	S2/S3/S5		Allocated sensor for thermostat function (S3 for T3, S2 for T2, S5 for T5)
		AHO	40℃	0.0-95℃	0.5℃	Switch-on temperature
		AHF	45℃	0.0-94.5℃	0.5℃	Switch-off temperature
		t A1O	00:00	00:00-23:59		Start time of the first time section
		t A1F	23:59	00:00-23:59		Close time of the first time section
		t A2O	00:00	00:00-23:59		Start time of the second time section
		t A2F	00:00	00:00-23:59		Close time of the second time section
		t A3O	00:00	00:00-23:59		Start time of the third time section
		t A3F	00:00	00:00-23:59		Close time of the third time section
	BEEP		OFF	ON/OFF		Beeper warning function (sensor fault, no flow)

Function Setting

● TIME (Timer function) Setting

- ▶ Select AUX main menu, press “SET”, to access TIME submenu
- ▶ Press “SET”, “TIME OFF” displays on the screen
- ▶ Press “SET”, “OFF” blinks
- ▶ Press “+/-”, to activate this function, “TIME ON” displays
- ▶ Press “SET” or “ESC” to save the setting
- ▶ Press “+”, “t1O 00:00” displays on the screen
- ▶ Press “SET”, hour “00” blinks
- ▶ Press “+/-”, to adjust hour of the start time of the first section



TIME
OFF



TIME
On



t1O
0000

- ▶ Press "SET", minute "00" blinks
- ▶ Press "+/-", to adjust minute of the start time of the first section
- ▶ Press "SET" or "ESC" to save the setting
- ▶ Press "+", "t1F 00:00" displays on the screen
- ▶ Press "SET", hour "00" blinks
- ▶ Press "+/-", to adjust the hour of the close time of the first time section
- ▶ Press "SET", minute "00" blinks
- ▶ Press "+/-" to adjust the minute of the close time of the first time section
- ▶ Press "SET" or "ESC" to save the setting
- ▶ Press "+", access the setting of the second time section, repeat above steps to set time of second and third sections.



t1F
00:00

If you want to close the timer for one section, just set a same time for the start and close time (e.g. 10:00 start, 10:00 close)

● AH (Thermostats function) setting

- ▶ Select AH submenu, "AH" displays on the screen
- ▶ Press "SET", "AH OFF" displays
- ▶ Press "SET", "OFF" blinks
- ▶ Press "+/-", to activate this function, "AH ON" displays on the screen
- ▶ Press "SET" or "ESC" to save the setting
- ▶ Press "+", "AHS S3" displays on the screen
- ▶ Press "SET", "S3" blinks
- ▶ Press "+/-", to select the object sensor for thermostat function
- ▶ Press "SET" or "ESC" to save the setting
- ▶ Press "+", "AHO 40°C" displays
- ▶ Press "SET", "40°C" blinks
- ▶ Press "+/-", to adjust the switch-on temperature
- ▶ Press "SET" or "ESC" to save the setting
- ▶ Press "+", "AHF 45°C" displays
- ▶ Press "SET", "45°C" blinks
- ▶ Press "+/-", to adjust the switch-off temperature of thermostat function
- ▶ Press "SET" or "ESC" to save the setting
- ▶ Press "+", "tA1O 00:00" displays
- ▶ Press "SET", hour "00" blinks
- ▶ Press "+/-", to adjust the hour of start time of the first time section



AH
OFF



AH
On



AHS
S3



AHO
40.0°C



AHF
45.0°C



tA1O
00:00

- ▶ Press “SET”, minute “00” blinks
- ▶ Press “+/-”, to adjust the minute of start time of the first time section
- ▶ Press “SET” or “ESC” to save the setting

- ▶ Press “+”, “tA1F 23:59” displays on the screen



- ▶ Press “SET”, “23” blinks

- ▶ Press “+/-”, to adjust the hour of close time of the first time section

- ▶ Press “SET”, “59” blinks

- ▶ Press “+/-”, to adjust the minute of close time of the first time section

- ▶ Press “SET” or “ESC” to save the setting

- ▶ Press “+”, access the setting of the second time section, repeat above steps to set time of second and third sections.

If you want to close the thermostat function for one section, just set a same time for the start and close time (e.g. 10:00 start, 10:00 close)

● BEEP (Beeper warning function) setting

- ▶ Select BEEP submenu, “BEEP” displays on the screen



- ▶ Press “SET”, “BEEP OFF” displays on the screen

- ▶ Press “SET”, “OFF” blinks

- ▶ Press “+/-”, to activate this function, “BEEP ON” displays on the screen




- ▶ Press “SET” or “ESC” to save the setting

8.6 MAN Manual operation

For control and service work, the operating mode of the relays can be manually adjusted. For this purpose, select the adjustment menu MAN (for R1, R2, R3, HR) to set output “On/OFF” Manually.

 **Note:** When manual mode is activated, sign  blinks on the screen, controller runs for 15 minutes and then switch-off all outputs, control exits manual mode automatically.

Menu structure

Main Menu	Submenu	Factory set	Adjustable range	Description
MAN				Manual mode
	R1	OFF	ON/OFF	R1 on and off
	R2	OFF	ON/OFF	R2 on and off
	R3	OFF	ON/OFF	R3 on and off
	HR	OFF	ON/OFF	HR on and off

Function setup

- ▶ Select “MAN” main menu.
- ▶ Press “SET”, “R1 OFF” displays
- ▶ Press “SET”, “OFF” blinks
- ▶ Press “+/-”, to activate this function, “R1 ON” displays
- ▶ Press “SET” or “ESC” to save the setting
- ▶ Press “+”, “R2” displays, repeat above steps to set the manual output of R2, R3, HR.


MAN

R1
OFFR1
On

Note: when a output is triggered manually, only this output is triggered, others running output will be stopped.

8.7 BLPR Blocking protection**Function description:**

In order to protect the pumps against blocking after standstill, the controller is equipped with a blocking protection function. This function switches on the relays one after another every day at 12:00 a.m and let them run for 10s.

Menu Structure

Function setting

- ▶ Select BLPR main menu,
- ▶ Press “SET”, “BLPR OFF” displays
- ▶ Press “SET”, “OFF” blinks
- ▶ Press “+/-”, to activate this function, “BLPR ON” displays on the screen
- ▶ Press “SET” or “ESC” to save the setting


BLPR

BLPR
OFFBLPR
On**8.8 OTDI Thermal Sterilization Function****Function description:**

This function helps to prevent the spread of Legionella in DHW tanks by systematically activating the after-heating.

For thermal disinfection, the temperature at the allocated sensor has to be monitored. During the monitoring period PDIS, this protection ensures the disinfection temperature is continuously exceeded the disinfection temperature TDIS for the entire disinfection period DDIS. Thermal disinfection can only be completed when the disinfection temperature is exceeded for the duration of the disinfection period without any interruption.

The monitoring period PDIS starts as soon as the temperature at the allocated sensor falls below the disinfection temperature TDIS, once the monitoring period PDIS ends, disinfection period SDIS starts, and the allocated reference relay activates the after-heating, when tank temperature exceeds the disinfection temperature, disinfection phase DDIS starts and disinfection heating time countdowns, countdown finishes, disinfection heating finishes.

Menu Structure

Menu	Submenu	Factor y set	Adjustable range	Step per adjust	Description
OTDI		OFF	ON/OFF		Disinfection function
	PDIS	7d	0-30d	1d	Time section of disinfection monitoring
	DDIS	10min	1-180	1min	Heating time of disinfection
	TDIS	70℃	0-90℃	1℃	Temperature of disinfection

	SDIS	18:00	00:00-21:00	1:00	Start time of disinfection
--	------	-------	-------------	------	----------------------------

Function setting

- ▶ Select OTDI main menu
- ▶ Press "SET", "OTDI OFF" display
- ▶ Press "SET", "OFF" blinks
- ▶ Press "+/-", to activate this function, "OTDI ON" displays
- ▶ Press "SET" or "ESC" to save the setting
- ▶ Press "+", "PDIS 7" displays
- ▶ Press "SET", "7" blinks
- ▶ Press "+/-", to adjust the days for disinfection monitoring,
- ▶ Press "SET" or "ESC" to save the setting



- ▶ Press "+", "DDIS 10Min" displays on the screen
- ▶ Press "SET", "10" blinks
- ▶ Press "+/-", to adjust the heating time of disinfection
- ▶ Press "SET" or "ESC" to save the setting
- ▶ Press "+", "TDIS 70°C" displays on the screen
- ▶ Press "SET", "70°C" blinks
- ▶ Press "+/-", to adjust the temperature of disinfection
- ▶ Press "SET" or "ESC" to save the setting
- ▶ Press "+", "SDIS 18:00" displays on the screen
- ▶ Press "SET", "18" blinks
- ▶ Press "+/-", to adjust the start time of the disinfection
- ▶ Press "SET" or "ESC" to save the setting



8.9 FS Flow rate monitoring and pump dry-running protection

Function Description:

In order to achieve flow rate monitoring, an extra digital flow counter FRT (see accessories) is needed, and it is installed on the solar return pipe, when solar pump R1 runs, the flow rate in the system is monitored, and it keeps the system runs properly.

If relay R1 is powered, flow rate of flow sensor will be monitored. After 30 seconds, if no flow rate is detected, then solar pump R1 is ceased, and error message will appear, and at the same time sign   blinks on the screen. It can avoid damaging system, for example, avoiding pump dry running. Under the main display screen, press "+/-", you can view the flow rate value. When error appears, press "+/-" to check the flow rate value, you can press

“SET” button for 3 seconds to switch-off FS function, and after the fault is removed, then monitoring function is activated again.

Flow monitoring function is designed to detect whether flow exists in the solar system and therefore to switch-off the corresponding pump in case of no flow,

If “OFF” option of the flow monitoring function is activated, and then the loaded tank is stopped to be heated until error message is removed, then monitoring function is activated again.

i Note: reasons of no flow in the solar system:


- No flow due to pipe leakage in system
- Circuit pump is damaged.
- Digital flow counter is blocked or damaged.

Under this menu, it is possible to activate or deactivate the flow monitoring function.

If flow monitoring function is activated, flow sign  displays on the screen, and under the checking status, current flow can be checked L/M

i Note: digital flow counter FRT is not listed in the standard delivery, user should buy it separately (see item 12 Accessories).

Menu Structure



Main menu	Sub menu	Factory set	Adjust able range	Step per adjust	Description
FS	OFF	OFF	OFF / ON		Flow monitoring function

Function setting

- ▶ Select FS main menu
- ▶ Press “SET”, “FS OFF” displays
- ▶ Press “SET”, “OFF” blinks
- ▶ Press “+/-”, to activate this function, “FS ON” displays
- ▶ Press “SET” or “ESC” to save the setting




8.10 UNIT C-F Switch

Under this menu, below unit can be set:

Unit of temperature can be switched between Celsius and Fahrenheit

Manual Structure



Function setting

- ▶ Select UNIT menu
- ▶ Press “SET”, “TEMP °C” displays on the screen
- ▶ Press “SET”, “°C” blinks
- ▶ Press “+/-”, to select temperature unit
- ▶ Press “SET” or “ESC” to save the setting


UNIT

TEMP
°C

8.11 RET Reset

RSTP (Menu parameters): through reset function, all parameters can be reset to factory setting

Manual structure



Function setting


- ▶ Select RST menu
- ▶ Press “SET”, “RSTP” displays on the screen
- ▶ Press “SET”, “YES” blinks
- ▶ Press “SET” for 3 seconds, beeper sounds “di” 3 times, “YES” lighting, and it indicates system is recovered to factory set.
- ▶ Press “ESC” return to the submenu
- ▶ Press “ESC” again, return to the main menu

RST

RSTP

YES

8.12 PASS Password set



Function Setting

Select PASS main menu,

- ▶ Press “SET” button, “PWDN 0000” displays on the screen,
- ▶ Press “SET” button again, the left first digital blinks, ask for entering the new password
- ▶ Press “+/-” button, to enter the first digital.
- ▶ Press “SET” button again, the second digital blinks,
- ▶ Press “+/-” button, to enter the second digital.
- ▶ Press “SET” button again, the third digital blinks,
- ▶ Press “+/-” button, to enter the third digital.
- ▶ Press “SET” button again, the forth digital blinks,
- ▶ Press “+/-” button, to enter the forth digital.
- ▶ Press “SET” button again, “PWDG 0000” displays on the screen, to enter the new password again, after confirm the new password, “OK” displays on the screen, it indicates the new password setting successfully.



Note: If the password is forgot, it is impossible to recover, but you can recover the password to factory set, then you can reedit a password like above descript steps, doing like following to recover to factory set.

- Switch-off the power to controller
- Hold down “ESC” button
- Reconnect the power supply, when beeper sounds 3 di di di, and then release “ESC” button, Controller recovers to the factory set password (factory set password is 0000),

8.13 Manual heating

Function Description:

It is possible to trigger back-up heating manually with this controller to heat tank. When tank temperature is lower than the set point of the switch-on temperature of this function, manual

heating function is in standby, then when you press the manual heating button, heating will start, and it works until tank temperature reaches to the set point.

Activate/deactivate this function:

► Press “Manual Heating” button, temperature “60°C” blinks on the screen

► Press “+/-” button to adjust the desired temperature, adjustable range 10°C~80°C, factory set is 60°C

► Press “Manual Heating” or “ESC” or waiting for 20 seconds to trigger the manual heating, then manual sign  displays on the screen, heating sign  blinks the screen

► Press “Manual Heating” again, switch-off the manual heating.



Note: Manual heating is not a continuous heating process, it is triggered manually, and when the temperature reaches to the set point, the heating process is stopped. And manual heating function is stopped automatically.

8.14 ECO Economic mode

Function description:

Under the ECO economic mode, timing heating and intelligent heating functions are switched-off, only manual heating mode (M.H) can be used to trigger the electrical heater.

Activate/deactivate this function:

► Press “ECO Mode” button, sign  displays, it indicates Eco mode is on.

► Press “ECO Mode” button again, sign  closed, it indicates the ECO mode is off.

8.15 DHW circuit pump triggered manually



Note: Only when function of DHW circuit pump CIRC is activated, it is just possible to trigger the output R2 manually for running the DHW circuit pump. (Default pump runs for 3 minutes)

► Press “” one time, to trigger the DHW circuit pump R2

► Press “” again, to cease the manual output.

8.16 On/Off controller

Under the on status

► Press  button for 3 seconds; controller is switched-off, “OFF” shows on the screen.

► Repress  button again, controller restarted.

8.17 Holiday function

The holiday function is used for operating the system when no water consumption is expected, e. g. during a holiday absence. This function cools down the system in order to reduce the thermal load.

Activate/deactivate this function:

► Press “Holiday” button for 3 seconds, “HDAY 05” displays on the screen



► Press “+/-”, to adjust holiday’s days, adjustable range 0-99 days

► Press “ESC” to save set, holiday function is activated and holiday sign  displayed and lighted.

► After holiday function is activated, and then press “Holiday” button to cease this function, holiday sign  displayed but not lighted.

 **Note:** When you return from holiday, please deactivate this function in time.

8.18 Manual circuit function

► Press “Manual Circuit” button, circuit pump R1 is triggered and runs for 1 hour.

► Press “Manual Circuit” button, to switch- off the circuit pump R1.



During the running of circuit pump R1, if you don’t press “Manual circuit” button, then R1 will run for 1 hour, then it is stopped automatically. And manual circuit function is deactivated correspondingly.

9. Protection function

9.1 Memory function during power failure


When power of controller is failed, and when power is switched-on, controller will keep the parameters which set before power failure.

9.2 Screen protection

When no any press on button for 5 minutes, screen protection is activated automatically, and then LED background lamp is switched-off. Through press any button to light LED lamp again.

10 Trouble checking

The built-in controller is a qualified product, which is conceived for years of continuous trouble-free operation. If a problem occurs, the most of causes is from the peripheral components but no relation with controller itself. The following description of some well-known problems should help the installer and operator to isolate the problem, so that the system can be put into operation as quickly as possible and to avoid unnecessary cost. Of course, not all possible problems can be listed here. However, most of the normal problems encountered with the controller can be found in the list below, only return the controller to seller when you are absolutely sure that none of the problems listed below is responsible for the fault.



PT1000 resistance value

℃	0	10	20	30	40	50	60	70	80	90	100	110	120
Ω	1000	1039	1077	1116	1155	1194	1232	1270	1309	1347	1385	1422	1460

NTC 10K B=3950 resistance value

℃	0	10	20	30	40	50	60	70	80	90	100	110	120
Ω	33620	20174	12535	8037	5301	3588	2486	1759	1270	933	697	529	407

Error Code Explanation




Error code	Meaning	Reasons and solution
E0	Communication fault between display and controller	1. White wire broken or not well connected. 2. Communication fault of display or controller
SMAx---/T3--- alternately displays	Sensor of tank maximum temperature (SMAx) is set to T3 or sensor fault	1. Under main menu (load)to select T2 sensor used for the tank maximum temperature function(SMAx) 2. T3 on upper part of tank is not installed 3. T3 sensor is damaged.
THS---/T3--- alternately displays	Sensor of heating object (THS)is set to T3 or sensor fault	1. Under main menu (THET) to select sensor T2 used for the objective sensor. 2. T3 on upper part of tank is not installed 3. T3 sensor is damaged.
AHS---/T3--- alternately displays	Sensor of thermostat function (AHS)is set to T3 or sensor fault	1. Under submenu AH of auxiliary function menu(AUX) to select sensor T2 used for the thermostat sensor 2. T3 on upper part of tank is not installed 3. T3 sensor is damaged.

11. Quality Guarantee


Manufacturer provides following quality responsibilities to end-users: within the period of quality responsibilities, manufacturer will exclude the failure caused by production and material selection. A correct installation will not lead to failure. When a user takes incorrect handling way, incorrect installation, improper or crude handling, and wrong connection of Warm water outflow upwards, we don't take the responsibilities caused by before mentioned actions.

The quality warranty expires within 18 months after the date of purchasing the controller.

12. Accessories

Products name	Specification	Products picture
A01: High accurate Pt1000 sensor for collector	PT1000, $\Phi 6 \times 50\text{mm}$	
A02 High accurate sensor for tank and pipe	NTC10K, B=3950, $\Phi 6 \times 50\text{mm}$	
A05 304 stainless steel thermo well	304 stainless steel with thread 1/2" OT, Size: $\Phi 8 \times 200$	
Digital flow counter FRT (A17)	Connection: Male thread 3/4 Power: 5-24V/DC	
SR802 Unit for high power electrical heater	Dimension: 100mm*100mm*65mm Power supply: AC180V ~ 264V, 50/60Hz Suitable power: $\leq 4000\text{W}$ Available ambient temperature: $-10 \sim 50^{\circ}\text{C}$ Waterproof grade: IP43	

● SR802 connection diagram



Note: Switch-off power, and perform by profession installer.